

## TUBE-STYLE SCAT MACHINE

# OPERATING INSTRUCTIONS

- If SCAT machine door is CLOSED, PRESS BLUE ACTIVATE button and wait for an audible CLICK before opening.
- If SCAT machine door is OPEN, PROCEED with further instructions.



1. Pull Clamping Mechanism and place tube-style toilet right side up on hopper door.
2. Release Clamping Mechanism (no straps needed).
3. Remove lid and place in accessory rack as shown.
4. Gently close the hopper door — DO NOT SLAM!
  - Your toilet will empty its contents into the machine as it positions over the cleaning wand to be sanitized.
5. Press GREEN START button and wait for wash cycle to complete.
6. Open hopper door and remove toilet and accessories.
  - If your toilet needs a second wash, leave in place and close the hopper door to start second wash cycle.

### To Fit Machine, Tubes Must Be:

- Schedule 20/Irrigation PVC pipe
- 4" diameter and 14" - 16" long